




GENERAL ATOMICS
AND AFFILIATED COMPANIES



Foam Shell Fabrication R&D at General Atomics



Don Czechowicz
Abbas Nikroo
Reny Paguio
Masa Takagi



Presented at the 2nd US-Japan Workshop
2-3 February, 2003
General Atomics, San Diego, CA



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Goal of Work:

Fabricate foam shells for U of R LLE- direct drive


$\approx 100\text{-}250 \text{ mg/cc}$

$\approx 1 \text{ mm diameter}$

$\approx 30\text{-}100 \text{ }\mu\text{m wall}$

Permeation seal barrier- $\approx <1 - 3 \text{ }\mu\text{m}$

Implosion insensitive to as much as 30 at. % oxygen



GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Foam shell fabrication history when our work began:

- Takagi, et al (ILE) - methacrylate-based chemistry
TMPT, EGDM- early '90s- *W/O/W system*
- LLNL/Schafer- reproduced ILE results- mid 90's
- LLNL/Schafer/ Soane -Resorcinol-Formaldehyde (R/F) reverse
oil/water/oil system, late 90's- *“reverse” O/W/O system*
- Schafer- work had begun on DVB shell fabrication - *W/O/W system*



GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



W/O/W systems were investigated initially

TMPT, EGDM, and DVB shells were made


These types of foam shells were opaque optically

Characterization is a big issue


R/F was chosen due to its transparency- reverse O/W/O system



DVB shells made using
microencapsulation (~ 2 mm in diameter)



X-radiograph of a
DVB shell



DVB shells are transparent only in liquid



GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES




Resorcinol-Formaldehyde Chemistry Used

- Cluster nucleation and growth




- F/R controls functionality of substituted resorcinol
- R/C controls cluster size
- Cluster aggregation catalyzed by acid



Substituted Resorcinol

R/F Clusters (70-100 Å)

Clusters aggregate to form gel network



GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Challenges in R/F shell fabrication:

- Reverse system (O/W/O) - lots of oil!
- Stability of emulsion- LLNL experience
- Curing of shells without buckling
- Dehydration from curing shell by surfactant/agitation
- Shell buckling due to removal of inner oil core from shell
- Circular voids present in shell wall
- CO₂ critical point drying of shells
- Fabrication of spherical and concentric shells





GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



LLNL work indicated problem with emulsion stability



LLNL experience indicated rapid gelation is necessary
Rapid gelation : not enough time for centering : poor NC

We found:

Proper density match leads to very stable preforms



GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Density matching is key for stable shell preform production

Density Oil-1 $\simeq$ Density W-1(R/F)

Stable during droplet generation

Stable during collection

Stable during curing (can cure at room temp!)

More concentric shells

Density Oil-1+W $\geq$ Oil-2

For proper agitation in rotavap flasks



GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES



Candidate O1, O2 Phases

<u>Liquid</u>	<u>Density (g/cc at R.T.)</u>
R/F solution	1.018
Light mineral oil (l.m.o.)	0.853
Tetrachloroethylene (TECE)	1.624
Carbon Tetrachloride	1.593
DiButyl Phthalate	1.042
1-Methyl Naphthalene	1.015

As long as preform is stable at R.T. : best to density match near curing temp.




GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Batch views from R/F shell fabrication




Shells are $\sim 1000 \mu\text{m}$ diameter $\approx 80 \mu\text{m}$ wall thickness
 4π non-concentricity $\approx 4\text{-}8 \%$



GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Optical view of dry R/F foam shells
($\approx 1200 \mu\text{m}$ OD $\approx 80 \mu\text{m}$ wall, 90 mg/cc)





GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Shell wall thinning in IPA can take place along with diameter expansion from insufficient curing




GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Density Increases as Wall Thickness Decreases for Shells within a Batch



Extended curing is critical




GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES



Catalyst Concentration Observed to Influence Cell Size and Opacity of RF Product



**low benzoic acid
concentration ->
clear foam**



**high benzoic acid
concentration ->
cloudy foam**



GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Progress Made in Overcoating of RF Shells

- **GDP coating of dried RF shells, 2-8 μm layers**
 - coating retains Argon-permeation similar to GDP
 - GDP/RF shell has higher buckle strength than GDP alone
- **PVP coating of RF shells, 1-4 μm layers**
 - coating retains Argon- permeation similar to GDP
 - PVP coated RF shells have extremely high strength



GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES




GDP coating was initially used as an overcoating for R/F

Relatively smooth coatings have been deposited on R/F shells



RMS = 810 Å
75 mtorr



RMS = 410 Å
500 mtorr

Higher pressure coatings lead to smoother surfaces- better pore closure



GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES



GDP Coating of R/F shells

$\approx 4 \mu\text{m}$ GDP coating on R/F foam



- GDP does close up R/F foam pores even at 2-3 um thickness




GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



GDP coatings do act as permeation seal barrier



Ar Gas Retention Testing by XRF

GDP thickness 3.3-4.7 μm

- 49 GDP coated shells tested
- 34 shells held Ar by XRF

*~70% shells tested had
gas-tight GDP coating*

compare:

PVP-coated 90%




GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



GDP coatings on R/F shells provide a gas barrier



Argon permeation data provided direct evidence of gas retention of GDP coated shells




GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Polyvinylphenol (PVP) Coating Process



IPA isopropyl alcohol
DEP diethylphthalate
IPC isophthaloyl dichloride
HEC hydroxyethylether cellulose



GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES




SEM examination of PVP Coated R/F Shells


PVP Coated RF Shell




Cross section



Acid chloride residue



Proper washing



GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES



Interferometric surface roughness measurement

RMS = 16 nm



WYKO interferometer data




GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



PVP coatings also have high mode roughness comparable to GDP coatings




- PVP coatings have rougher high mode power spectra compared to GDP coatings!
- AFM patch scans, however, indicate somewhat better PVP background (high mode) surface finish
- GDP overcoat of PVP smoothes coating as seen by spheremapper and patch AFM




GENERAL ATOMICS
AND AFFILIATED COMPANIES



PVP coated shells were smoothed by GDP overcoating



PVP Coated R/F shell



GDP coated PVP Coated R/F shell



GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



PVP Coated RF Shells are observed to have higher buckle strength

<u>Shell</u>	<u>Norm Buckle Strength (psi)</u>
Std-GDP	1.5
Std-GDP coated RF	2.0
<i>PVP coated RF</i>	<i>3.0</i>

Normalized buckle strength corresponds to 900 μ m OD shell with a 1 μ m Wall

Std-GDP is standard Glow Discharge Polymer, deposited at 75 mtorr



GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



SUMMARY

- Significant Progress on RF Shell Fabrication and Coating
- Shells of ~ 1.0 mm diameter, 60-100 μm wall, and ~ 100 mg/cc density have been fabricated and coated by GDP and PVP
- Several overcoated shells were tested for gas retention, and sent to LLE - One shell (5 μm GDP overcoat) was filled with 1000 atm D₂ and cooled to cryogenic temperatures - Shell survived
- D₂ was frozen and layered - first time in U.S. using foam shell




GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES



During curing dehydration of shells can occur



Shells in Oil-2



Dehydration can be caused by;

- Too much surfactant in O2
- Vigorous agitation during curing
- Too long of cure
- *Happens in mineral oil- (low water solubility)*
- Wrinkling is somewhat smoothed out in IPA

Shells in IPA





GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Rapid transport of O1 phase from interior during curing or IPA exchange can buckle shells



1-methyl naphthalene
used as O1




GENERAL ATOMICS



GENERAL ATOMICS
AND AFFILIATED COMPANIES



Slow removal of O1 core from cured shell in IPA





GENERAL ATOMICS





GENERAL ATOMICS
AND AFFILIATED COMPANIES



**We have observed the growth of circular voids
in shell wall upon exposure to IPA**



**Side-Views of Circular
Voids in Shell Wall**



GENERAL ATOMICS




GENERAL ATOMICS
AND AFFILIATED COMPANIES



Droplet Generator used for R/F Shell R&D Triple Orifice Osaka Design

Droplet Generator



**Rotary Flask mainly used
Blades System also examined**



GENERAL ATOMICS